



**For shallow application in loose seedbed soil
Maximum 5" depth**

The Sub-Surface Shoe has been in service long before the current trend in deep placement. This conventional tape application can be done before or after planting. In-line spacing on single toolbar is only limited by roll size. Nearly any specialized offset spacing is possible with a double toolbar.

For tape removal, see Plastic Removal Equipment.



3-row

6155

- Shank & shoe works in LOOSE SOIL
- Category 2 hitch, quick-hitch compat
- 4" square toolbar
- Shoe-type applicator mounted on spring-loaded parallel-linkage
- Optional gauge wheels for each shoe
- 4-bolt gauge wheels for toolbar
- Single or double tape roll supports

Optional gauge wheels shown



6-row

Combined & Custom Set-Ups

Drip Tape Applicators are commonly installed on bed shapers, mulch layers or planters for practical combination of field passes. With bed shapers in particular, tapes lines are buried as beds are formed for a smooth finish.

See Drip Tape Applicators - Universal Set-Up for a full description of roll supports and tape shanks or guides.

